


MindCloud Studio

User Manual v1.0.0_EN



Catalogue

1. Introduction	4
2. Download and Authorization	5
2.1 Recommended computer configuration	5
2.2 Download and Install	6
2.3 Software License Agreement	7
3. Software Interface Introduction	8
3.1 Main Interface	8
3.2 File bar	9
3.3. Tools bar	10
3.4 Industry bar	11
3.5. Setting bar	12
3.6 Project Management directory	13
3.7 Property directory	14
3.8 3D View window	15
4. Basic Operations	16
4.1 Language Switch	16
4.2. Block Loading	17
4.3 Task Creation and Point Cloud Loading	18
4.4 RTK Optimization	20
4.5 GCP Optimization	27
4.6 Zooming, Translation, and Rotation of Point Clouds	30
4.7. Adjustment of Particle Size	31
4.8. Render method changed	32
4.9 Data Export	33
4.10. Batch Processing	34
5. Common Functions	36
5.1 Point Selection	36
5.2 Measurement	37
5.3 Segment	38

5.4 Cross Section	39
5.5. Section Mode	40
5.6 Point Cloud Orientation	41
5.7 Filter by value	42
5.8 Sample	43
5.9 Registration	44
5.10. Merge	48
5.11 Control Point Report	49
5.12. Roam	50
5.13. New 3D View	51
6. Industry Applications	54
6.1. Mesh	54
6.2 Robot	58
6.3. Earthwork	60
6.4 Scene Export	65

1. Introduction

Welcome to MindCloud Studio.

MindCloud Studio is a professional 3D point cloud processing software independently developed by Manifold Tech Ltd., compatible with all of the company's scanner devices. Specifically designed for handling '.lx' point clouds and '.plx' files generated by Manifold Tech Ltd.'s products, it accurately analyzes the data, fully unlocks its value, and lays a solid foundation for subsequent data processing.

In terms of functional features, it boasts robust data processing capabilities, including the following:

- The loading and processing of point cloud data are highly efficient, while advanced algorithms ensure optimal point cloud quality.
- An intelligent sampling strategy that adjusts the sampling density based on data characteristics to optimize storage and rendering speeds.
- Its advanced filtering algorithm accurately removes noise while preserving details, thereby enhancing data quality.
- Supports real-time interactive analysis, allowing users to receive immediate data feedback for flexible strategy adjustments.
- The interface features a clean and intuitive design with a well-organized layout, clear icons and text labels that make it easy for both beginners and professionals to use.
- The software features a linear and smooth operation workflow, supports exporting data in mainstream formats, offers simple parameter settings, and provides real-time preview for easy adjustments.

With its superior compatibility and powerful features, MindCloud Studio has become a pivotal tool for point cloud processing, significantly driving technological innovation and business expansion across multiple domains. It stands out uniquely in the industry, offering exceptional practical value and competitive advantages.

2. Download and Authorization

2.1 Recommended computer configuration

MindCloud Studio is recommended for use on computers running Windows 10 or later (64-bit) that meet specific configuration requirements.

Minimum Requirements	
Operating System	Windows 10 or later
Processor	Intel Core i5 or better
Installed Memory	16 GB DDR4 or better
Video Card	NVIDIA GeForce RTX 2050 or better
Storage Space	256 GB or more

Recommended Requirements	
Operating System	Windows 10 or later
Processor	Intel Core i7 or better
Installed Memory	32 GB DDR5 or better
Video Card	NVIDIA GeForce RTX 3050 or better
Storage Space	512 GB or more

2.2 Download and Install

Users who have purchased products from Manifold Tech Ltd. can visit the version management page of the software to download the latest version of MindCloud Studio at the following URL: <https://version.manifoldtech.cn/download/mcs>, or scan the QR code below to access the corresponding download page.



Customers who have not purchased products but need to trial the software can visit the official website at <https://www.manifoldtech.cn/>, complete the application form, and download the trial installation package, or contact the sales channel to obtain the software and case study data.



MindCloud申请试用

地区* 请选择省 请选择市 请选择区/县

公司/组织* 请填写您的公司/组织

所属行业* 请填写您的所属的行业

姓名* 请填写您的姓名

电话* +86 请填写您的电话

邮箱* 请填写您的邮箱

可联系我司工作人员，告知上述信息


申请试用

2.3 Software License Agreement

MindCloud Studio has undergone a comprehensive upgrade. To ensure seamless integration between this software and products, Manifold Tech Ltd. has decided to issue a license for MindCloud Studio.

After receiving the device, please contact the dealer or manufacturer's staff to complete online or local authorization and obtain the corresponding license.


- (1) Network Authorization: Click "Online Apply", fill in the required information, and wait for backend confirmation to complete the authorization immediately.
- (2) Local Authorization: Send the Device UUID code to the distributor or manufacturer personnel to generate the license file offline. On the computer, click "Import Authorization File" and manually import the license.



Software License



Network Authorization




Local Authorization

3. Software Interface Introduction

3.1 Main Interface


The main interface of MindCloud Studio can be simply divided into seven major sections, as shown in the figure below:




main interface

region	name	content
1	File bar	Guide and create point cloud projects, and import and export files
2	Tools bar	Includes common point cloud editing features such as measurement, cropping, sectioning, registration, and merging.
3	Industry bar	It includes advanced industry features such as mesh generation, building construction, forestry surveying, pile measurement, and intelligent robotics.
4	Settings bar	View and configure the software's window information and authorization details
5	Project Management directory	Show the various data objects loaded by the software
6	Property directory	Show the relevant attributes of the selected data object
7	3D View window	Show all loaded data objects


3.2 File bar



For new projects, you can load and optimize point clouds, open and view existing projects, and import or export data in various other formats, as shown below:




Point Cloud Processing



Import data format


3.3. Tools bar



The toolbar includes the following features:

- Point Picking: Annotate points in the point cloud and view individual point attributes.
- Point List: Annotate points in the point cloud and record their attribute information in a list format for easy manual selection of control points.
- Distance: Measures the distance between two points.
- Area: Measures the area of a triangle formed by three points.
- Segment: Polygon crop point cloud, save internal/external region..
- Cross Section: Manually control the bounding box of the point cloud, adjust the length and angles of its six axes, and save the point cloud within the box to create point cloud slices.
- Section Mode: Use a rectangle of specified thickness to section the point cloud from a top view, and display the measurements in another view.
- Point Cloud Orientation: Reorient the position and orientation of the point cloud through translation and rotation.
- Filter By Value: Segment the point cloud before and after based on its attributes.
- Subsample: Use different methods to reduce the point cloud density by decreasing the number of points.
- Registration: Includes "Align (point-to-point selection)" and "Fine Registration (ICP)", allowing manual stitching and alignment of point clouds.
- Merge: Combine the selected multiple point cloud datasets.
- Scans Fusion: Integrates standalone high-definition or panoramic photos into a point cloud view.
- Control Point Report: This can be optimized for GCP. After optimizing the control points, their accuracy is verified and a report file is generated.
- Roam: Use the WASD keys to move the view freely, just like controlling a character
- New 3D View: Adjust the number, position, and relationships of multiple window views.


3.4 Industry bar



The industry functions include the following:

- Mesh: Convert the point cloud into a triangular mesh model.
- Simplify Mesh: Reduce the number of grid model patches.
- Texture: Map photos to a mesh model to create a texture effect.
- Navigation Map: Generates a repositioning map for embodied intelligent products, enabling navigation, obstacle avoidance, and other functions.
- .USD Export: Convert point cloud data or other 3D data into USD format, compatible with the NVIDIA Omniverse simulation platform.
- Earthwork Measurement: Calculate the volume difference between the stack and the reference plane, and measure the volume.
- Earthwork Comparison: Calculate the volume difference between the pile surface surfaces obtained from the two scans, and measure the fill and excavation volumes.
- MipMap Export: Convert photos saved by the Liuxing Space Intelligent Product into a distortion-free data structure compatible with the mipmap software, enabling third-party Gaussian rendering.
- CC Export: Convert photos captured by the Liuxing Space intelligent product into a distortion-free data structure compatible with the iTwin software (formerly CC, ContextCapture), enabling third-party mesh reconstruction.


3.5. Setting bar



The bar includes the following features:

- **Language:** Switch the software's text language. The change takes effect after restarting the software.
- **Log Path:** Go to the software log folder recorded by the MindCloud Studio software.
- **Cloud License:** Check software authorization status.
- **User Manual:** Go to and open the software's user manual.
- **Check for New Version:** View the software update information.


3.6 Project Management directory



The project management directory displays the currently loaded data objects. Click a cell to determine the display status of the data object:

- Check: Show in view.
- Do not check: Hide in view.

3.7 Property directory



The property directory contains the following information, using point cloud data as an example:

- **Name:** View the name of the selected point cloud data object.
- **Visible:** Click to check or uncheck to display or hide the selected point cloud object data.
- **Colors:** You can switch between RGB or scalar fields to display point cloud colors.
- **Box size and center:** View the bounding box of the point cloud object data, which serves as a geometric container holding the entire point cloud. You can view the box's size and position.
- **Points:** View the number of points in the point cloud.
- **Global shift:** The globally applied uniform translation value for the point cloud in the coordinate system.
- **Global scale:** The unified scaling ratio applied globally to the point cloud in the coordinate system.
- **Point size:** Adjust the point size.
- **Scalar Fields:** Switches between different point cloud attributes to determine the current rendering basis for point cloud colors, where Intensity represents reflection intensity and Label indicates the time frame.

3.8 3D View window






The center of the 3D view window displays all visible object data. There are shortcut buttons on the left with the following functions:

- Display Settings: Adjust software configurations such as background color, lighting conditions, and data loading strategies.
- Camera Settings: Adjust the view angle and position of the current view.
- Global Zoom: Fit all object data within the current view.
- Center View: Switch between perspective projection and orthogonal projection.
- Zoom and Center Selected Entities: Display the selected object data prominently in the view.
- Select Rotation Center: Manually pick the center point for rotating the object data.
- Auto-select Rotation Center: Automatically choose the rotation center of the object data, typically the center of the view.
- Top View: View the object data from a top-down perspective.
- Front View: View the object data from a front-facing perspective..

4. Basic Operations

4.1 Language Switch


- (1) In Settings, click Language to switch the language, then reopen the software to change the language again.



Switch language

4.2. Block Loading


- (1) In the 3D view window, click the "Display Settings" shortcut button, check the "Move Simplification" option, and save with the configured values. Unchecking this option will fully load the data.



Block Loading


4.3 Task Creation and Point Cloud Loading

- (1) Click "Single Point Cloud" under "New Project" to enter the point cloud processing configuration interface.



Click on the Single Point Cloud

- (2) In the configuration interface, you can select the point cloud to load based on the path, choose standard optimization options, and configure parameters such as point cloud resolution, loading the raw point cloud, saving point cloud normal vectors, and robust mode.




Point Cloud Processing Configuration Interface

- (3) There are three standard optimization options: loop detection, adjustment optimization, and moving object filtering, each serving the following purposes:
- **Loop Closure:** Used to determine whether the SLAM scanner has re-scanned previously traversed scenes, thereby correcting cumulative errors. This technique is typically employed when scanning paths intersect or overlap, eliminating layering effects caused by accumulated errors in repetitive scenes and enhancing the map's integrity and consistency.
 - **Bundle Adjustment:** Eliminates minor errors in local scenes and, through comprehensive calculation, distributes the errors uniformly across the entire scene rather than accumulating them solely at the periphery. This approach reduces noise and subtle layering effects, effectively decreasing the point cloud thickness.
 - **Moving Object Filtering:** Reduces the point cloud of moving objects during scanning, primarily targeting noise from passing pedestrians and vehicles.
- (4) Point cloud resolution refers to the distance between points, measured in millimeters, and controls the density and detail accuracy of the point cloud. A smaller value indicates a denser point cloud with richer details; the default is 2 mm, while 0 mm and 1 mm represent the original resolution.
- (5) Loading the raw point cloud refers to generating both the original and optimized point clouds during point cloud processing.
- (6) The saving of point cloud normal vectors refers to calculating and outputting the normals of each point in the point cloud relative to the surface during point cloud processing.
- (7) The Robust Mode refers to switching to this processing mode, which significantly reduces memory usage by leveraging the hard drive, though it offers slower processing speeds and requires sufficient disk space—making it suitable for running large-scale point clouds on memory-constrained devices. The default mode is Fast Mode, which processes data using memory for maximum speed but demands substantial memory capacity, ideal for small to medium datasets. Robust Mode is only activated when manually selected.
- (8) Finally, click OK to start loading and optimizing the point cloud.

4.4 RTK Optimization



- (1) When processing point clouds, if the engineering data contains GNSS positioning data recorded by RTK, RTK optimization is automatically displayed.
- (2) In the Configuration section, you can select a coordinate transformation method. The default is "Coordinate Reference System," which converts the point cloud's relative coordinates to the target ellipsoid + projection coordinate system and may include additional correction parameters.





RTK optimal configuration

(3) In RTK optimization configuration, the source coordinate reference system automatically reads the coordinate system broadcast by the CORS account used within RTK, while the target reference system is the final converted coordinate system, which requires manual configuration.

- The commonly used coordinate system in China is CGCS2000 combined with the Gauss 3-degree zone projection, where the central meridian depends on the local longitude;
- Additionally, the internationally recognized WGS84 + UTM projection transformation method is employed.



(4) Meanwhile, within the target coordinate system parameters, users can configure various system parameters — including ellipsoid parameters, projection parameters, translation correction (Calibration parameters), seven-parameter (Datum Transform), four-parameter (plane transform), and Height fitting — as well as import the geoid model and NTV2 grid.



Ellipsoid Parameters

Target CRS: WGS 84 / UTM zone 49N Select...

Target CRS Parameters

Ellipsoid **Projection** Calibration Parameters Datum Transform Plane Transform

Parameter	Value
Projection Method	Transverse Mercator
Central Meridian (deg)	111.00000000
Latitude of Origin (deg)	0.00000000
Scale Factor at Natural Origin	0.99960000
False Easting (m)	500000.000000
False Northing (m)	0.000000
Standard Parallel 1 (deg)	0.00000000
Standard Parallel 2 (deg)	0.00000000
Projection Plane Origin Height (m)	0.000000

Projection Parameter

Target CRS: WGS 84 / UTM zone 49N Select...

Target CRS Parameters

Ellipsoid Projection **Calibration Parameters** Datum Transform Plane Transform

Parameter	Value
Use Transform	No
dx (m)	0.000000
dy (m)	0.000000
dz (m)	0.000000

Translation Correction (Calibration Parameter)

Target CRS: WGS 84 / UTM zone 49N Select...

Target CRS Parameters

Ellipsoid Projection Calibration Parameters **Datum Transform** Plane Transform

Parameter	Value
Use Transform	No <input type="checkbox"/>
dx (m)	0.000000
dy (m)	0.000000
dz (m)	0.000000
rx (arcsec)	0.000000
ry (arcsec)	0.000000
rz (arcsec)	0.000000
scale (ppm)	0.000000

Seven parameters (Datum Transform)

Target CRS: WGS 84 / UTM zone 49N Select...

Target CRS Parameters

Ellipsoid Projection Calibration Parameters Datum Transform **Plane Transform**

Parameter	Value
Use Transform	No <input type="checkbox"/>
dx (m)	0.0000000000
dy (m)	0.0000000000
theta (deg)	0.0000000000
scale (ppm)	0.0000000000

Four parameters (Plane Transform)

Target CRS: WGS 84 / UTM zone 49N Select...

Target CRS Parameters

Projection Calibration Parameters Datum Transform Plane Transform Height Fitting

Coefficient	Value
Use Transform	No <input type="checkbox"/>
a0	0.0000000000
a1	0.0000000000
a2	0.0000000000
a3	0.0000000000
a4	0.0000000000
a5	0.0000000000
a6	0.0000000000
a7	0.0000000000
a8	0.0000000000
a9	0.0000000000

Height Fitting

- (5) RTK optimization also allows customization of the external parameters for input RTK frames. However, when using the accompanying frames, no additional steps are required — the software automatically reads the frame's external parameters and applies the default settings directly.
- (6) For GNSS data recorded by RTK, there is a "GPS filtering level" to assess the quality of GNSS positioning data, with the default setting being medium.

GPS Filter Level Help

GPS Filter Level controls how strictly GPS data points are filtered before optimization.

Strict:
Recommended when RTK signal is strong (open-sky, good satellite visibility). Stricter filtering produces higher accuracy and reduces the impact of outliers, but fewer GPS points will be used.


Medium (Recommended):
A balanced setting suitable for most scenarios. Provides a good trade-off between data quality and quantity.

Relaxed:
Recommended when RTK signal is poor (urban canyons, partial obstruction). More GPS points will participate in optimization, helping the point cloud better align with the GPS coordinate system. However, lower-quality GPS data may introduce distortion or anomalies in the point cloud.

OK

4.5 GCP Optimization

- (1) When processing point clouds, if the engineering data contains control point information collected during field surveys, the system automatically displays GCP optimization—specifically, control point optimization.



Control Point Optimization

- (2) Select Configuration, then import the CSV file containing the geographic coordinate data of control points. Ensure the order of control points matches that in the coordinate file, and correctly map the north and east coordinates to the Y-axis and X-axis, respectively.

Import Target Points

Import File: data/MT20260214-153139-gcp/image/gcp副本/留形园区道路控制点_WGS84_UTM49N - 副本.csv

local controlPoints

target controlPoints

ID	X	Y	Z	
<input checked="" type="checkbox"/>	1	28.761002	-2.380823	0.223712
<input checked="" type="checkbox"/>	2	315.163679	-31.476632	1.243193
<input checked="" type="checkbox"/>	3	301.156761	-203.840300	3.322462
<input checked="" type="checkbox"/>	4	277.772290	-336.297410	6.956223
<input checked="" type="checkbox"/>	5	44.715473	-314.697194	7.107936
<input checked="" type="checkbox"/>	6	-133.347488	-304.059000	7.428089
<input checked="" type="checkbox"/>	7	-297.595260	-286.556866	7.608708
<input checked="" type="checkbox"/>	8	-275.521683	-132.426346	3.587138
<input checked="" type="checkbox"/>	9	-263.124940	23.645310	0.596823
<input checked="" type="checkbox"/>	10	-118.867734	12.301420	2.414296

ID	Y	X	Z
1	2495258.7660...	797972.576000	6.078000
2	2495547.2380...	797967.346000	6.650000
3	2495553.9490...	798140.661000	8.151000
4	2495546.4100...	798275.094000	11.502000
5	2495311.8090...	798280.970000	11.540000
6	2495133.0560...	798292.161000	11.501000
7	2494967.3250...	798294.907000	11.014000
8	2494971.0960...	798138.561000	7.027000
9	2494965.3870...	797981.735000	4.002000
10	2495110.5640...	797975.536000	5.379000

confirm cancel

Note: Typically, the north coordinate points upward to the Y-axis of the point cloud, and the east coordinate points to the right to the X-axis of the point cloud.

(3) The CSV file template containing control point coordinate data is as follows, typically comprising four columns: point number, north coordinate, east coordinate, and elevation, with no header:


	A	B	C	D
1	1	2493370.8	489396.97	6.078
2	2	2493659.1	489397.54	6.65
3	3	2493662.3	489570.83	8.151
4	4	2493652.1	489704.99	11.502
5	5	2493417.6	489706.15	11.54
6	6	2493238.8	489713.75	11.501

Control Point CSV Template

4.6 Zooming, Translation, and Rotation of Point Clouds

By combining various mouse button combinations, you can zoom, pan, and rotate the point cloud. The methods are as follows:


- (1) Left-click and hold to rotate the control point cloud;
- (2) Right-click and hold to pan the control point cloud;
- (3) Roll the wheels up and down to zoom the point cloud;
- (4) Long-press and drag the roller to quickly zoom the point cloud.
- (5) Within the point cloud, double-click the left or right button or use the scroll wheel to reset the rotation center.



Zoom, Pan, Rotate

4.7. Adjustment of Particle Size

- (1) After selecting the point cloud, adjust the point size value in the properties box or change the default global point size in the upper-left corner of the view.




Adjust point size

4.8. Render method changed


This feature allows you to freely transform point clouds into color renderings with various attributes.

- (1) Select the point cloud, then click Color in the properties window to switch from "RGB" to "Scalar field," after which you can freely choose different color scales.



Scalar field

- (2) Alternatively, replace "Intensity" with "Label" in the active scalar field; the software will then render the point cloud based on the scanning time.




Label


4.9 Data Export

Export point cloud data or meshes separately to other formats, and save them in multiple formats.

- (1) Select the point cloud, right-click to save, or click the Export button in the file bar.



derive data





Different formats of point clouds

4.10. Batch Processing


You can import multiple sets of engineering data and process them sequentially.

- (1) Under the File bar, select "Batch Processing" to import the project data folder to be processed.



Batch Import


(2) Continue configuring the processing options for each set of engineering data, then start batch processing.



5. Common Functions


5.1 Point Selection

- Click to select points: Left-click to choose points within the point cloud to display their information.



reconnaissance


- Click the point list, right-click to select multiple points, and the information of all selected points—including global coordinates—will be saved in the table on the right. You can export the data as table files in various formats.



Point List


5.2 Measurement

- Click Distance measures the length between two points in a point cloud. Left-click to select points; the value appears when the two points are connected. "Distance" indicates the length, measured in meters.



distance


- Click on the area, right-click to select points, and connect the three points to form a surface. The value will appear; "area" represents the area, measured in square meters.



area

5.3 Segment

- Select the point cloud and click "Crop" on the toolbar;
- Left-click to select points and draw lines; select the target point cloud with a box; right-click to finish drawing the lines.
- You can choose either the internal or external point cloud of the selected area, then click "Apply" to complete.




Point Cloud Cropping

- Click Pause to stop the current crop operation, release the fixed view, and allow you to move the view again. Click Pause again to continue the crop operation.

5.4 Cross Section


- Left-click to select the point cloud, then click "3D Trim" in the toolbar;
- Drag the arrows and circles in all six directions of the bounding box to adjust its size and angle.
- After adjusting to the appropriate angle, click the "Export Slices" button on the right toolbar.



3D裁剪

5.5. Section Mode

- Left-click to select the point cloud, then click "Section View" on the toolbar.
- Check the option for a fixed slice width, which defaults to 0.1 m (10 cm).
- In the main view, select the point cloud scene to be sectioned; the sectioned point cloud will be displayed in the right cross-section view from a front view.



View in Section

- Meanwhile, in the section view, click the third button above to measure the length of a specific scene, such as viewing the point cloud thickness.





Cross-section triangle

- You can also click the fourth button to save the cut point cloud separately.

5.6 Point Cloud Orientation

- Left-click to select the point cloud, then click "Point Cloud Orientation" on the toolbar.
- You can reconfigure the X, Y, and Z axes from three perspectives: top view, front view, and left view. Adjust the point cloud orientation to reorient it.
- In the top view, you can redefine the orientation of the X and Y axes. Click Apply Rotation to adjust the point cloud direction accordingly.




Redirect the XY axes in the top view


- The same operation can also modify the point cloud orientation in the front view and left/right views, then click Save.

5.7 Filter by value

- Select the point cloud and click "Filter by Value" on the toolbar to export or split the point cloud individually based on the active scalar field— "Intensity" or "Label" —attribute values.




Intensity attribute



Label attribute

5.8 Sample

- Select the point cloud and click "Resampling" on the toolbar to reduce its density using algorithms such as random percentages or point cloud spatial intervals.



double sampling


5.9 Registration

- Hold down the Ctrl key to select two point cloud datasets, then click "registration" on the toolbar. Two registration methods are available: "Align (Point-to-Point)" and "Fine Registration (ICP)".

1) Align (point-to-point): Manually select corresponding feature point pairs from two point clouds and then register the point clouds.



2) Integrated Cloud Registration (ICP): The ICP algorithm automatically performs global matching between two point clouds, followed by registration of the point clouds.

- Taking ICP as an example, click "Fine Registration (ICP)" to align the point clouds and the reference point cloud, set the overlap rate parameters, then click OK to begin the conversion.




ICP

- For point-to-point selection, hold the Ctrl key to select two point clouds, then click "Align (Point-to-Point)" to align the point clouds with the reference point cloud.





Manual registration

- To identify common feature point pairs between two point clouds, it is recommended to use objects such as cross targets or calibration plates.
- After selecting feature points, information will be displayed on the right side; the selection order of the two point clouds must remain consistent.




- Click Align to view the registration results of the two point cloud datasets, then click Apply to complete the registration.



Point Cloud Registration

5.10. Merge

- Hold the Ctrl key to select multiple point cloud groups, then click "Merge" on the toolbar.



merge

5.11 Control Point Report

- In point cloud processing, selecting GCP optimization allows for control point accuracy verification after optimization.
- Select the point cloud, click "Control Point Report" on the toolbar, check the optimized point cloud, import the original control point file, and finally click "Calculate". You can also export the inspection results as a PDF file for easy storage.

Control Point Report

Name

- (D:/mindcloud_data/MT20260214-153139-gcp)
 - MANIFOLD_MT20260214-153139-Opt**
 - Octree
 - Trajectory-Opt
 - Octree

File: D:/mindcloud_data/MT20260214-153139-gcp/image/gcp副本/扇形园区道路控制点_CGCS2000_高斯114 - 副本.csv Import Control Points

Matching Parameters

Z Tolerance: 0.150 Max Slope (deg): 45.00 Max Edge Length: 20.000

Results

Name	Ctrl X	Ctrl Y	Ctrl Z	Match X	Match Y	Match Z	Res X	Res Y	Res Z	Res Total
1	489396.9...	2493370...	6.078	0.000	0.000	0.000	0.000	0.000	0.000	0.000
2	489397.5...	2493659...	6.650	0.000	0.000	0.000	0.000	0.000	0.000	0.000
3	489570.8...	2493662...	8.151	0.000	0.000	0.000	0.000	0.000	0.000	0.000
4	489704.9...	2493652...	11.502	0.000	0.000	0.000	0.000	0.000	0.000	0.000
5	489706.1...	2493417...	11.540	0.000	0.000	0.000	0.000	0.000	0.000	0.000
6	489713.7...	2493238...	11.501	0.000	0.000	0.000	0.000	0.000	0.000	0.000
7	489713.1...	2493073...	11.014	0.000	0.000	0.000	0.000	0.000	0.000	0.000
8	489557.0...	2493080...	7.027	0.000	0.000	0.000	0.000	0.000	0.000	0.000
9	489400.2...	2493077...	4.002	0.000	0.000	0.000	0.000	0.000	0.000	0.000
10	489396.9...	2493222...	5.379	0.000	0.000	0.000	0.000	0.000	0.000	0.000

Compute Export PDF

Import control points

File: v/image/gcp副本/扇形园区道路控制点_CGCS2000_高斯114 - 副本.csv Browse...


Delimiter: Auto detect Delimiter

[Name]	[Y]	[X]	[Z]
<input checked="" type="checkbox"/> 1	2493370...	489396.972	6.078
<input checked="" type="checkbox"/> 2	2493659...	489397.536	6.65
<input checked="" type="checkbox"/> 3	2493662...	489570.831	8.151
<input checked="" type="checkbox"/> 4	2493652...	489704.991	11.502
<input checked="" type="checkbox"/> 5	2493417...	489706.154	11.54
<input checked="" type="checkbox"/> 6	2493238...	489713.748	11.501
<input checked="" type="checkbox"/> 7	2493073...	489713.166	11.014
<input checked="" type="checkbox"/> 8	2493080...	489557.035	7.027
<input checked="" type="checkbox"/> 9	2493077...	489400.236	4.002
<input checked="" type="checkbox"/> 10	2493222...	489396.955	5.379

OK Cancel

5.12. Roam

- Select the point cloud and click "Roam" on the toolbar to switch to first-person view. Use the WASD keys to move the view, the QE key to adjust its height, and the scroll wheel to zoom the field of view.




go on a pleasure trip


5.13. New 3D View

In the toolbar, click "New 3D View" to access the following features:


- New View
- View Linkage
- Tile
- Cascade
- Close All



Among them, the new view allows viewing different point clouds across multiple windows.




Create View and Switch Views



Multi-view point cloud display


View synchronization allows all point clouds in multiple windows to move, rotate, and scale synchronously, enabling coordinated action.

The flat layout arranges all views in binary rectangles;



Tile

The cascade window displays all views in an indexed arrangement within a single window, showing only the current view while hiding the others.




Cascading Window

6. Industry Applications


6.1. Mesh

6.1.1 Mesh

- Select the point cloud, click "Mesh" in the industry toolbar, and choose the meshing resolution (low, medium, or high; the default is medium). Click OK to generate the mesh model. The file will be automatically saved in the project directory in.ply format or can be saved in another format.




Triangle Grid Generation



Mesh

6.1.2 Simplify Mesh


- Select the Mesh and click "Simplify Mesh" in the industry toolbar to reduce the number of mesh faces, thereby decreasing the data size. However, this will also compromise some accuracy and fit quality.



Grid Simplification


6.1.3 Texture

- Select the Mesh, then click "Texture" in the industry toolbar. The software will automatically calculate and map the photo onto the Mesh, generating a mesh model with the photo texture.




texture mapping

- After starting the process, the calculation speed depends on your computer's performance.
- After completing the texture mapping, save it in the project data directory under a folder named "model".



Grid Model Results Save Directory




Mesh Model

6.2 Robot

6.2.1 Navigation Map


- Select the point cloud and click "Navigation Map" under the Industry Applications section to generate another series of localization maps used by Odin, an embodied intelligent product, which facilitates navigation algorithms. For details, see:

https://manifoldtechltd.github.io/wiki/odin_series/odin1/10.%20Relocalization%20Usr%20Guide.html.



6.2.2 .USD Export


- Select the point cloud and click "USD Export" under Industry Functions to export the data in USD format, facilitating integration with the NVIDIA Omniverse simulation training platform.



6.3. Earthwork


6.3.1. Earthwork Measurement

- Before using the stack for measurement, the stack must first be trimmed or the unnecessary point clouds on its edges and top removed.




Cutting

- Next, select the cropped point cloud of the volume and click "Volume Measurement" in the Industry Applications section.



Pile mass measurement


- Use the "Polygon Selection" manual box to select the occupied area of the stack;
- To set the reference plane, use the "Three-Point Plane" tool to select three points from the point cloud as the reference plane.
- Select a method for calculating the volume; the recommended option is the "Triangulated Inverse Network (TIN)". This will generate the pile information and allow you to export the report.




Stack Information

6.3.2 Earthwork Comparison

- Similar to pile body measurement, it is recommended to first register and align the two point cloud datasets, then crop the pile body or remove the redundant point clouds from the periphery and top.




Point cloud registration and alignment




Crop stack


- Select two sets of embankment point clouds, click "Embankment Comparison" under the industry toolbar, specify the pre-and post-embankment configurations along with the calculation method, and finally compute the fill and cut volumes.



Stack Comparison



Select the front and rear pile bodies





Calculation of fill and excavation work



6.4 Scene Export

6.4.1 MipMap Export

- Select the point cloud and click "MipMap Export" in the industry toolbar. The system will automatically generate the required data structure folder for MipMap software based on the selected point cloud and its corresponding project.
- After that, use MipMap to import the corresponding converted folder for Gaussian reconstruction.





MipMap Export





MipMap data structure folder

6.4.2 CC Export

- Select the point cloud and click "CC Export" in the industry toolbar. The system will automatically generate the required data structure folder for CC software (formerly Context Capture; now iTwin Capture Modeler) based on the selected point cloud and its corresponding project.
- After that, use CC to import the converted folder for 3D reconstruction.



CC leading-out



CC Data Structure Folder